

MAKE YOUR OWN WORM DRIVE CLIPS

MAKES ANY
DIAMETER CLIP
FROM 20 mm DIA.
TO 450 mm DIA.

CLIP-KIT

SOLE AUSTRALIAN AGENT

**I & M
Industries**

(INCORPORATED IN VICTORIA)

2 JOEL COURT, MOORABBIN, VIC 3189
TELEPHONE 555 6955

MADE IN U.K.

THE "CLIP-KIT" SYSTEM

"CLIP-KITS" consist of either zinc plated or stainless steel continuously serrated banding which can be formed into worm drive clips when cut to length and fitted with housing and screw.



STRANGLEHOLD "CLIP-KIT"

Consists of 30 metres of continuously serrated 11 mm wide zinc plated or stainless steel banding in a dispenser pack with separate housings and screws.



SLIMLINE "CLIP-KIT"

Consists of 25 metres of continuously serrated 7 mm wide stainless steel banding in a dispenser pack with separate "Fliplock" captive screws.



HANDY PACK "CLIP-KIT"

Consists of a 1.5 metre coil of SLIMLINE continuously serrated 7 mm wide stainless steel banding with 5 separate "Fliplock" captive screws.

**MAKES ANY
DIAMETER CLIP
FROM 50 mm DIA.
TO 450 mm DIA.**

CLIP KIT

MADE IN U.K.

STRANGLEHOLD 11 mm WIDE ZINC PLATED OR STAINLESS STEEL BANDING **MAKES ANY DIAMETER CLIP FROM 50 mm TO 450 mm DIA.**

MAKE THE SIZE CLIP YOU WANT...QUICKLY, EASILY



Measure banding to required length, add approx. 40 mm and cut.



Insert banding through housing until end protrudes 12 mm then bend end under.



Feed other end of banding around objects to be clamped and through slot in housing.



Insert screw and tighten with a screwdriver.

MAKE YOUR OWN WORM DRIVE CLIPS

Measure banding to required length, add approx. 40 mm and cut.

Insert end protrudes 12 mm then bend end under "Fiplock" housing

Feed other end of banding around objects to be clamped and through slot at other end of "Fiplock" housing

Insert screw under "Fiplock" housing and tighten using screwdriver

Distributed by



I & M Industries

2 Joel Court, Moorabbin, Victoria, Australia 3189
P.O. Box 165, Moorabbin, Victoria 3189
Telephone: (03) 555 6955. Fax: (03) 555 6465